

# CatDancer® Wall Scratcher

A SCRATCH &  
PLAY STATION

Cat Dancer® cat toy is included  
to attach to the Wall Scratcher for  
hours of fun!



Holds on strongly with  
four strips included



Command® Strips hold the Wall Scratcher securely to the wall without damage. Strips come off cleanly without leaving any adhesive residue.

Easy to install and the designer pattern fits into any decor.

The Wall Scratcher is vertical, just like your furniture and the trees cats scratch in the wild. Scratching is a cat's natural method to remove the outer sheath of their claws to expose the fresh healthy nail underneath.

**Replacement Cores  
Item #706**

**Item #705**

**CatDancerProducts** INC®



Command is a trademark of 3M.  
No endorsement implied

6145 GREEN VALLEY ROAD, NEENAH WI 54956  
PHONE 800.844.6369 • 920.426.4330 • FAX 920.426.4520  
www.catdancer.com

Made with pride and care in the USA

